

Code		Fuji Electric SCE Series Motor Contactors	Aust\$
F500	SC-E02-24VAC	Fuji IEC 9A contactor, non-reversing, 3-pole, 43 mm frame width, 24 VAC coil (purchase auxiliary contacts separately)	\$19
F501	SC-E02-110VAC	Fuji IEC 9A contactor, non-reversing, 3-pole, 43 mm frame width, 110-120 VAC coil (purchase auxiliary contacts separately)	\$19
F502	SC-E02-220VAC	Fuji IEC 9A contactor, non-reversing, 3-pole, 43 mm frame width, 220-240 VAC coil (purchase auxiliary contacts separately)	\$19
F503	SC-E02G-24VDC	Fuji IEC 9A contactor, non-reversing, 3-pole, 43 mm frame width, 24 VDC coil (purchase auxiliary contacts separately)	\$22
F560	SC-E02-440VAC	Fuji IEC 9A contactor, non-reversing, 3-pole, 43mm frame width, 440-480 VAC coil (purchase auxiliary contacts separately)	\$19
F504	SC-E03-24VAC	Fuji IEC 12A contactor, non-reversing, 3-pole, 43 mm frame width, 24 VAC coil (purchase auxiliary contacts separately)	\$25
F505	SC-E03-110VAC	Fuji IEC 12A contactor, non-reversing, 3-pole, 43 mm frame width, 110-120 VAC coil (purchase auxiliary contacts separately)	\$25
F506	SC-E03-220VAC	Fuji IEC 12A contactor, non-reversing, 3-pole, 43 mm frame width, 220-240 VAC coil (purchase auxiliary contacts separately)	\$25
F507	SC-E03G-24VDC	Fuji IEC 12A contactor, non-reversing, 3-pole, 43 mm frame width, 24 VDC coil (purchase auxiliary contacts separately)	\$35
F562	SC-E03-440VAC	Fuji IEC 12A contactor, non-reversing, 3-pole, 43mm frame width, 440-480 VAC coil (purchase auxiliary contacts separately)	\$25
F508	SC-E04-24VAC	Fuji IEC 18A contactor, non-reversing, 3-pole, 43 mm frame width, 24 VAC coil (purchase auxiliary contacts separately)	\$30
F509	SC-E04-110VAC	Fuji IEC 18A contactor, non-reversing, 3-pole, 43 mm frame width, 110-120 VAC coil (purchase auxiliary contacts separately)	\$30
F510	SC-E04-220VAC	Fuji IEC 18A contactor, non-reversing, 3-pole, 43 mm frame width, 220-240 VAC coil (purchase auxiliary contacts separately)	\$30
F511	SC-E04G-24VDC	Fuji IEC 18A contactor, non-reversing, 3-pole, 43 mm frame width, 24 VDC coil (purchase auxiliary contacts separately)	\$42
F564	SC-E04-440VAC	Fuji IEC 18A contactor, non-reversing, 3-pole, 43mm frame width, 440-480 VAC coil (purchase auxiliary contacts separately)	\$30
F513	SC-E05-110VAC	Fuji IEC 25A contactor, non-reversing, 3-pole, 43 mm frame width, 110-120 VAC coil (purchase auxiliary contacts separately)	\$39
F514	SC-E05-220VAC	Fuji IEC 25A contactor, non-reversing, 3-pole, 43 mm frame width, 220-240 VAC coil (purchase auxiliary contacts separately)	\$39
F515	SC-E05G-24VDC	Fuji IEC 25A contactor, non-reversing, 3-pole, 43 mm frame width, 24 VDC coil (purchase auxiliary contacts separately)	\$51
F566	SC-E05-440VAC	Fuji IEC 25A contactor, non-reversing, 3-pole, 43mm frame width, 440-480 VAC coil (purchase auxiliary contacts separately)	\$39
F512	SC-E05-24VAC	Fuji IEC 25A contactor, non-reversing, 3-pole, 43mm frame width, 24 VAC coil (purchase auxiliary contacts separately)	\$39
F516	SC-E1-24VAC	Fuji IEC 32A contactor, non-reversing, 3-pole, 54 mm frame width, 24 VAC coil (purchase auxiliary contacts separately)	\$48
F517	SC-E1-110VAC	Fuji IEC 32A contactor, non-reversing, 3-pole, 54 mm frame width, 110-120 VAC coil (purchase auxiliary contacts separately)	\$48
F518	SC-E1-220VAC	Fuji IEC 32A contactor, non-reversing, 3-pole, 54 mm frame width, 220-240 VAC coil (purchase auxiliary contacts separately)	\$48
F519	SC-E1G-24VDC	Fuji IEC 32A contactor, non-reversing, 3-pole, 54 mm frame width, 24 VDC coil (purchase auxiliary contacts separately)	\$56
F568	SC-E1-440VAC	Fuji IEC 32A contactor, non-reversing, 3-pole, 54mm frame width, 440-480 VAC coil (purchase auxiliary contacts separately)	\$48
F520	SC-E2-24VAC	Fuji IEC 40A contactor, non-reversing, 3-pole, 54 mm frame width, 24 VAC coil (purchase auxiliary contacts separately)	\$67
F521	SC-E2-110VAC	Fuji IEC 40A contactor, non-reversing, 3-pole, 54 mm frame width, 110-120 VAC coil (purchase auxiliary contacts separately)	\$67
F522	SC-E2-220VAC	Fuji IEC 40A contactor, non-reversing, 3-pole, 54 mm frame width, 220-240 VAC coil (purchase auxiliary contacts separately)	\$67
F523	SC-E2G-24VDC	Fuji IEC 40A contactor, non-reversing, 3-pole, 54 mm frame width, 24 VDC coil (purchase auxiliary contacts separately)	\$81
F570	SC-E2G-440VAC	Fuji IEC 40A contactor, non-reversing, 3-pole, 54mm frame width, 440-480 VAC coil (purchase auxiliary contacts separately)	\$67
F524	SC-E2S-24VAC	Fuji IEC 50A contactor, non-reversing, 3-pole, 54 mm frame width, 24 VAC coil (purchase auxiliary contacts separately)	\$81
F525	SC-E2S-110VAC	Fuji IEC 50A contactor, non-reversing, 3-pole, 54 mm frame width, 110-120 VAC coil (purchase auxiliary contacts separately)	\$81
F526	SC-E2S-220VAC	Fuji IEC 50A contactor, non-reversing, 3-pole, 54 mm frame width, 220-240 VAC coil (purchase auxiliary contacts separately)	\$81
F527	SC-E2SG-24VDC	Fuji IEC 50A contactor, non-reversing, 3-pole, 54 mm frame width, 24 VDC coil (purchase auxiliary contacts separately)	\$96
F572	SC-E2S-440VAC	Fuji IEC 50A contactor, non-reversing, 3-pole, 54mm frame width, 440-480 VAC coil (purchase auxiliary contacts separately)	\$81
F528	SC-E3-24VAC	Fuji IEC 65A contactor, non-reversing, 3-pole, 67 mm frame width, 24 VAC coil (purchase auxiliary contacts separately)	\$91
F529	SC-E3-110VAC	Fuji IEC 65A contactor, non-reversing, 3-pole, 67 mm frame width, 110-120 VAC coil (purchase auxiliary contacts separately)	\$91
F530	SC-E3-220VAC	Fuji IEC 65A contactor, non-reversing, 3-pole, 67 mm frame width, 220-240 VAC coil (purchase auxiliary contacts separately)	\$91
F531	SC-E3G-24VDC	Fuji IEC 65A contactor, non-reversing, 3-pole, 67 mm frame width, 24 VDC coil (purchase auxiliary contacts separately)	\$117

F574	SC-E3-440VAC	Fuji IEC 65A contactor, non-reversing, 3-pole, 67mm frame width, 440-480 VAC coil (purchase auxiliary contacts separately)	\$91
F532	SC-E4-24VAC	Fuji IEC 80A contactor, non-reversing, 3-pole, 67 mm frame width, 24 VAC coil (purchase auxiliary contacts separately)	\$94
F533	SC-E4-110VAC	Fuji IEC 80A contactor, non-reversing, 3-pole, 67 mm frame width, 110-120 VAC coil (purchase auxiliary contacts separately)	\$94
F534	SC-E4-220VAC	Fuji IEC 80A contactor, non-reversing, 3-pole, 67 mm frame width, 220-240 VAC coil (purchase auxiliary contacts separately)	\$94
F535	SC-E4G-24VDC	Fuji IEC 80A contactor, non-reversing, 3-pole, 67 mm frame width, 24 VDC coil (purchase auxiliary contacts separately)	\$117
F646	SC-E4-440VAC	Fuji IEC 80A contactor, non-reversing, 3-pole, 67mm frame width, 440-480 VAC coil (purchase auxiliary contacts separately)	\$94
F536	SC-E5-24V	Fuji IEC 105A contactor, non-reversing, 3-pole, 88 mm frame width, SUPERMAGNET(tm) coil accepts 24 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$234
F537	SC-E5-100V	Fuji IEC 105A contactor, non-reversing, 3-pole, 88 mm frame width, SUPERMAGNET(tm) coil accepts 110-120 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$234
F538	SC-E5-200V	Fuji IEC 105A contactor, non-reversing, 3-pole, 88 mm frame width, SUPERMAGNET(tm) accepts 220-240 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$234
F648	SC-E5-400V	Fuji IEC 105A contactor, non-reversing, 3-pole, 88mm frame width, SUPERMAGNET(tm) coil accepts 380-450 VAC, includes 2 N.O. and 2 N.C. auxiliary contacts	\$234
F539	SC-E6-24V	Fuji IEC 125A contactor, non-reversing, 3-pole, 100 mm frame width, SUPERMAGNET(tm) coil accepts 24 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$298
F540	SC-E6-100V	Fuji IEC 125A contactor, non-reversing, 3-pole, 100 mm frame width, SUPERMAGNET(tm) coil accepts 110-120 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$298
F541	SC-E6-200V	Fuji IEC 125A contactor, non-reversing, 3-pole, 100 mm frame width, SUPERMAGNET(tm) coil accepts 220-240 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$298
F650	SC-E6-400V	Fuji IEC 125A contactor, non-reversing, 3-pole, 100mm frame width, SUPERMAGNET(tm) coil accepts 380-450 VAC, includes 2 N.O. and 2 N.C. auxiliary contacts	\$298
F542	SC-E7-24V	Fuji IEC 150A contactor, non-reversing, 3-pole, 100 mm frame width, SUPERMAGNET(tm) coil accepts 24 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$348
F543	SC-E7-100V	Fuji IEC 150A contactor, non-reversing, 3-pole, 115 mm frame width, SUPERMAGNET(tm) coil accepts 110-120 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$348
F544	SC-E7-200V	Fuji IEC 150A contactor, non-reversing, 3-pole, 115 mm frame width, SUPERMAGNET(tm) coil accepts 220-240 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$348
F544	SC-E7-400V	Fuji IEC 150A contactor, non-reversing, 3-pole, 115mm frame width, SUPERMAGNET(tm) coil accepts 380-450 VAC, includes 2 N.O. and 2 N.C. auxiliary contacts	\$348

		Fuji Electric Odyssey Series Motor Contactors	Aust\$
F545	3NC4Q0E22	Fuji IEC 180A contactor, non-reversing, 3-pole, 154 mm frame width, SUPERMAGNET(tm) coil accepts 24 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$460
F546	3NC4Q0122	Fuji IEC 180A contactor, non-reversing, 3-pole, 154 mm frame width, SUPERMAGNET(tm) coil accepts 110-120 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$460
F547	3NC4Q0222	Fuji IEC 180A contactor, non-reversing, 3-pole, 154 mm frame width, SUPERMAGNET(tm) coil accepts 220-240 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$460
F548	3NC4H0E22	Fuji IEC 221A contactor, non-reversing, 3-pole, 154 mm frame width, SUPERMAGNET(tm) coil accepts 24 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$545
F549	3NC4H0122	Fuji IEC 221A contactor, non-reversing, 3-pole, 154 mm frame width, SUPERMAGNET(tm) coil accepts 110-120 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$545
F550	3NC4H0222	Fuji IEC 221A contactor, non-reversing, 3-pole, 154 mm frame width, SUPERMAGNET(tm) coil accepts 220-240 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$545
F661	3NC4Q0Q22	Fuji IEC 180A contactor, non-reversing, 3-pole, 138mm frame width, SUPERMAGNET(tm) coil accepts 380-450 VAC, includes 2 N.O. and 2 N.C. auxiliary contacts	\$460
F663	3NC4H0Q22	Fuji IEC 221A contactor, non-reversing, 3-pole, 138mm frame width, SUPERMAGNET(tm) coil accepts 380-450 VAC, includes 2 N.O. and 2 N.C. auxiliary contacts	\$545
F551	3NC5F0E22	Fuji IEC 285A contactor, non-reversing, 3-pole, 169 mm frame width, SUPERMAGNET(tm) coil accepts 24 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$710
F552	3NC5F0122	Fuji IEC 285A contactor, non-reversing, 3-pole, 169 mm frame width, SUPERMAGNET(tm) coil accepts 110-120 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$710
F553	3NC5F0222	Fuji IEC 285A contactor, non-reversing, 3-pole, 169 mm frame width, SUPERMAGNET(tm) coil accepts 220-240 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$710
F554	3NC5H0E22	Fuji IEC 361A contactor, non-reversing, 3-pole, 169 mm frame width, SUPERMAGNET(tm) coil accepts 24 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$779
F555	3NC5H0122	Fuji IEC 361A contactor, non-reversing, 3-pole, 169 mm frame width, SUPERMAGNET(tm) coil accepts 110-120 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$779
F556	3NC5H0222	Fuji IEC 361A contactor, non-reversing, 3-pole, 169 mm frame width, SUPERMAGNET(tm) coil accepts 220-240 VAC or DC, includes 2 N.O. and 2 N.C. aux contacts	\$779
F665	3NC5F0Q22	Fuji IEC 285A contactor, non-reversing, 3-pole, 148mm frame width, SUPERMAGNET(tm) coil accepts 380-450 VAC, includes 2 N.O. and 2 N.C. auxiliary contacts	\$710
F667	3NC5H0Q22	Fuji IEC 361A contactor, non-reversing, 3-pole, 148mm frame width, SUPERMAGNET(tm) coil accepts 380-450 VAC, 50/60Hz coil, includes 2 N.O. and 2 N.C. auxiliary contacts	\$779

		Fuji Electric Thermal Overload Relays for SCE Series Contactors	Aust\$
F575	TK-E02-15	Fuji thermal overload relay, 53 mm frame width, FLA range 0.1 to 0.15 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F576	TK-E02-20	Fuji thermal overload relay, 53 mm frame width, FLA range 0.13 to 0.20 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F577	TK-E02-24	Fuji thermal overload relay, 53 mm frame width, FLA range 0.15 to 0.24 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F578	TK-E02-30	Fuji thermal overload relay, 53 mm frame width, FLA range 0.2 to 0.3 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F579	TK-E02-36	Fuji thermal overload relay, 53 mm frame width, FLA range 0.24 to 0.36 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F580	TK-E02-54	Fuji thermal overload relay, 53 mm frame width, FLA range 0.36 to 0.54 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F581	TK-E02-72	Fuji thermal overload relay, 53 mm frame width, FLA range 0.48 to 0.72 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F582	TK-E02-96	Fuji thermal overload relay, 53 mm frame width, FLA range 0.64 to 0.96 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F583	TK-E02-120	Fuji thermal overload relay, 53 mm frame width, FLA range 0.8 to 1.2 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F584	TK-E02-145	Fuji thermal overload relay, 53 mm frame width, FLA range 0.95 to 1.45 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F585	TK-E02-220	Fuji thermal overload relay, 53 mm frame width, FLA range 1.4 to 2.2 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F586	TK-E02-260	Fuji thermal overload relay, 53 mm frame width, FLA range 1.7 to 2.6 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F587	TK-E02-340	Fuji thermal overload relay, 53 mm frame width, FLA range 2.2 to 3.0 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F588	TK-E02-420	Fuji thermal overload relay, 53 mm frame width, FLA range 2.8 to 4.2 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F589	TK-E02-600	Fuji thermal overload relay, 53 mm frame width, FLA range 4 to 5 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F590	TK-E02-800	Fuji thermal overload relay, 53 mm frame width, FLA range 5 to 8 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F591	TK-E02-900	Fuji thermal overload relay, 53 mm frame width, FLA range 6 to 9 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F592	TK-E02-1100	Fuji thermal overload relay, 53 mm frame width, FLA range 7 to 11 amps. May only be used with Fuji SC-E02, SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F593	TK-E02-1300	Fuji thermal overload relay, 53 mm frame width, FLA range 9 to 13 amps. May only be used with Fuji SC-E03, SC-E04, SC-E05 43 mm wide contactors.	\$32
F594	TK-E02-1800	Fuji thermal overload relay, 53 mm frame width, FLA range 12 to 18 amps. May only be used with Fuji SC-E04, SC-E05 43 mm wide contactors.	\$32
F595	TK-E02-2200	Fuji thermal overload relay, 53 mm frame width, FLA range 16 to 22 amps. May only be used with Fuji SC-E05 43 mm wide contactors.	\$32
F596	TK-E02-2500	Fuji thermal overload relay, 53 mm frame width, FLA range 20 to 25 amps. May only be used with Fuji SC-E05 43 mm wide contactors.	\$32
F645	SZ-HCE	Base unit to allow separate mounting of TK-E02 series thermal overload relays to 35mm wide DIN rail or screw mounted to panel.	\$8
F597	TK-E2-600	Fuji thermal overload relay, 54 mm frame width, FLA range 4 to 6 amps. May only be used with Fuji SC-E1, SC-E2, SC-E2S 54 mm wide contactors.	\$51
F598	TK-E2-800	Fuji thermal overload relay, 54 mm frame width, FLA range 5 to 8 amps. May only be used with Fuji SC-E1, SC-E2, SC-E2S 54 mm wide contactors.	\$51
F599	TK-E2-900	Fuji thermal overload relay, 54 mm frame width, FLA range 6 to 9 amps. May only be used with Fuji SC-E1, SC-E2, SC-E2S 54 mm wide contactors.	\$51
F600	TK-E2-1100	Fuji thermal overload relay, 54 mm frame width, FLA range 7 to 11 amps. May only be used with Fuji SC-E1, SC-E2, SC-E2S 54 mm wide contactors.	\$51
F601	TK-E2-1300	Fuji thermal overload relay, 54 mm frame width, FLA range 9 to 13 amps. May only be used with Fuji SC-E1, SC-E2, SC-E2S 54 mm wide contactors.	\$51
F602	TK-E2-1800	Fuji thermal overload relay, 54 mm frame width, FLA range 12 to 18 amps. May only be used with Fuji SC-E1, SC-E2, SC-E2S 54 mm wide contactors.	\$51
F603	TK-E2-2600	Fuji thermal overload relay, 54 mm frame width, FLA range 18 to 26 amps. May only be used with Fuji SC-E1, SC-E2, SC-E2S 54 mm wide contactors.	\$51
F604	TK-E2-3600	Fuji thermal overload relay, 54 mm frame width, FLA range 24 to 36 amps. May only be used with Fuji SC-E1, SC-E2, SC-E2S 54 mm wide contactors.	\$51
F605	TK-E2-4200	Fuji thermal overload relay, 54 mm frame width, FLA range 32 to 42 amps. May only be used with Fuji SC-E1, SC-E2, SC-E2S 54 mm wide contactors.	\$51
F606	TK-E2-5000	Fuji thermal overload relay, 54 mm frame width, FLA range 40 to 50 amps. May only be used with Fuji SC-E1, SC-E2, SC-E2S 54 mm wide contactors.	\$51
F607	TK-E2-5400	Fuji thermal overload relay, 54 mm frame width, FLA range 44 to 54 amps. May only be used with Fuji SC-E1, SC-E2, SC-E2S 54 mm wide contactors.	\$51
F646	SZ-HDE	Base unit to allow separate mounting of TK-E2 series thermal overload relays to 35mm wide DIN rail or screw mounted to panel.	\$15
F608	TK-E3-1100	Fuji thermal overload relay, 68 mm frame width, FLA range 7 to 11 amps. May only be used with Fuji SC-E3, SC-E4 67 mm wide contactors.	\$62
F609	TK-E3-1300	Fuji thermal overload relay, 68 mm frame width, FLA range 9 to 13 amps. May only be used with Fuji SC-E3, SC-E4 67 mm wide contactors.	\$62
F610	TK-E3-1800	Fuji thermal overload relay, 68 mm frame width, FLA range 12 to 18 amps. May only be used with Fuji SC-E3, SC-E4 67 mm wide contactors.	\$62
F611	TK-E3-2600	Fuji thermal overload relay, 68 mm frame width, FLA range 18 to 26 amps. May only be used with Fuji SC-E3, SC-E4 67 mm wide contactors.	\$62

F612	TK-E3-3600	Fuji thermal overload relay, 68 mm frame width, FLA range 24 to 36 amps. May only be used with Fuji SC-E3, SC-E4 67 mm wide contactors.	\$62
F613	TK-E3-4000	Fuji thermal overload relay, 68 mm frame width, FLA range 28 to 40 amps. May only be used with Fuji SC-E3, SC-E4 67 mm wide contactors.	\$62
F614	TK-E3-5000	Fuji thermal overload relay, 68 mm frame width, FLA range 34 to 50 amps. May only be used with Fuji SC-E3, SC-E4 67 mm wide contactors.	\$62
F615	TK-E3-6500	Fuji thermal overload relay, 68 mm frame width, FLA range 45 to 65 amps. May only be used with Fuji SC-E3, SC-E4 67 mm wide contactors.	\$62
F616	TK-E3-6800	Fuji thermal overload relay, 68 mm frame width, FLA range 48 to 68 amps. May only be used with Fuji SC-E3, SC-E4 67 mm wide contactors.	\$62
F617	TK-E3-8000	Fuji thermal overload relay, 68 mm frame width, FLA range 64 to 80 amps. May only be used with Fuji SC-E4 67 mm wide contactors.	\$62
F647	SZ-HEE	Base unit to allow separate mounting of TK-E3 series thermal overload relays to 35mm wide DIN rail or screw mounted to panel.	\$18
F618	TK-E5-2600	Fuji thermal overload relay, 77 mm frame width, FLA range 18 to 26 amps. May only be used with Fuji SC-E5 88 mm wide contactors.	\$37
F619	TK-E5-3600	Fuji thermal overload relay, 77 mm frame width, FLA range 24 to 36 amps. May only be used with Fuji SC-E5 88 mm wide contactors.	\$37
F620	TK-E5-4000	Fuji thermal overload relay, 77 mm frame width, FLA range 28 to 40 amps. May only be used with Fuji SC-E5 88 mm wide contactors.	\$37
F621	TK-E5-5000	Fuji thermal overload relay, 77 mm frame width, FLA range 34 to 50 amps. May only be used with Fuji SC-E5 88 mm wide contactors.	\$70
F622	TK-E5-6500	Fuji thermal overload relay, 77 mm frame width, FLA range 45 to 65 amps. May only be used with Fuji SC-E5 88 mm wide contactors.	\$70
F623	TK-E5-9500	Fuji thermal overload relay, 77 mm frame width, FLA range 65 to 95 amps. May only be used with Fuji SC-E5 88 mm wide contactors.	\$70
F624	TK-E5-10500	Fuji thermal overload relay, 77 mm frame width, FLA range 85 to 105 amps. May only be used with Fuji SC-E5 88 mm wide contactors.	\$37
F625	TK-E6-6500	Fuji thermal overload relay, 100 mm frame width, FLA range 45 to 65 amps. May only be used with Fuji SC-E6 100 mm wide, and SC-E7 115 mm wide contactors.	\$120
F626	TK-E6-8000	Fuji thermal overload relay, 100 mm frame width, FLA range 53 to 80 amps. May only be used with Fuji SC-E6 100 mm wide and SC-E7 115 mm wide contactors.	\$120
F627	TK-E6-9500	Fuji thermal overload relay, 100 mm frame width, FLA range 65 to 95 amps. May only be used with Fuji SC-E6 100 mm wide and SC-E7 115 mm wide contactors.	\$120
F628	TK-E6-12500	Fuji thermal overload relay, 100 mm frame width, FLA range 85 to 125 amps. May only be used with Fuji SC-E6 100 mm wide and SC-E7 115 mm wide contactors.	\$120
F629	TK-E6-16000	Fuji thermal overload relay, 100 mm frame width, FLA range 110 to 160 amps. May only be used with Fuji SC-E7 115 mm wide contactors.	\$120

		Fuji Electric Thermal Overload Relays for Odyssey Series Contactors	Aust\$
F630	3NK4QK	Fuji thermal overload relay, 119 mm frame width, FLA range 65 to 95 amps. May only be used with Fuji 3NC4Q size contactors.	\$171
F631	3NK4QL	Fuji thermal overload relay, 119 mm frame width, FLA range 85 to 125 amps. May only be used with Fuji 3NC4Q size contactors.	\$171
F632	3NK4QN	Fuji thermal overload relay, 119 mm frame width, FLA range 110 to 160 amps. May only be used with Fuji 3NC4Q size contactors.	\$171
F633	3NK4QP	Fuji thermal overload relay, 119 mm frame width, FLA range 125 to 185 amps. May only be used with Fuji 3NC4Q size contactors.	\$171
F634	3NK4HL	Fuji thermal overload relay, 138 mm frame width, FLA range 85 to 125 amps. May only be used with Fuji 3NC4H size contactors..	\$204
F635	3NK4HN	Fuji thermal overload relay, 138 mm frame width, FLA range 110 to 160 amps. May only be used with Fuji 3NC4H size contactors.	\$204
F636	3NK4HP	Fuji thermal overload relay, 138 mm frame width, FLA range 125 to 185 amps. May only be used with Fuji 3NC4H size contactors.	\$204
F637	3NK4HQ	Fuji thermal overload relay, 138 mm frame width, FLA range 160 to 240 amps. May only be used with Fuji 3NC4H size contactors.	\$204
F638	3NK5HN	Fuji thermal overload relay, 142 mm frame width, FLA range 110 to 160 amps. May only be used with Fuji 3NC5F and 3NC5H size contactors.	\$334
F639	3NK5HP	Fuji thermal overload relay, 142 mm frame width, FLA range 125 to 185 amps. May only be used with Fuji 3NC5F and 3NC5H size contactors.	\$334
F640	3NK5HQ	Fuji thermal overload relay, 142 mm frame width, FLA range 160 to 240 amps. May only be used with Fuji 3NC5F and 3NC5H size contactors.	\$334
F641	3NK5HR	Fuji thermal overload relay, 142 mm frame width, FLA range 200 to 300 amps. May only be used with Fuji 3NC5F and 3NC5H size contactors.	\$334
F642	3NK5HS	Fuji thermal overload relay, 142 mm frame width, FLA range 240 to 360 amps. May only be used with Fuji 3NC5H size contactors.	\$334
F643	3NK5HT	Fuji thermal overload relay, 142 mm frame width, FLA range 300 to 450 amps. May only be used with Fuji 3NC5H size contactors.	\$334
		Fuji Electric Auxiliary Contacts for SCE Series Contactors	Aust\$
F675	SZ-A22T	Fuji front mounted auxiliary contact block for contactor sizes E02(G) to E4(G). Contains 2 N.O. and 2 N.C. contact blocks.	\$16
F676	SZ-A20T	Fuji front mounted auxiliary contact block for contactor sizes E02(G) to E4(G). Contains 2 N.O. contact blocks.	\$10
F677	SZ-A11T	Fuji front mounted auxiliary contact block for contactor sizes E02(G) to E4(G). Contains 1 N.O. and 1 N.C. contact blocks.	\$10
F678	SZ-AS1T	Fuji side mounted auxiliary contact block for contactor sizes E02(G) to E4(G). Contains 1 N.O. and 1 N.C. contact blocks.	\$16
F679	SZ-AS2T	Fuji side mounted auxiliary contact block for contactor sizes E5 to E7. Contains 1 N.O. and 1 N.C. contact blocks.	\$16
		Fuji Coil Surge Suppressors	Aust\$
F680	SZ-Z1	Fuji coil surge suppressor, varistor type, 24-48 VAC/DC for contactor sizes E02(G)-E05(G)	\$13
F681	SZ-Z2	Fuji coil surge suppressor, varistor type, 100-250 VAC/DC for contactor sizes E02(G)-E05(G)	\$13
F682	SZ-Z4	Fuji coil surge suppressor, RC type, 24-48 VAC/DC for contactor sizes E02(G)-E05(G)	\$14
F683	SZ-Z5	Fuji coil surge suppressor, RC type, 100-250 VAC/DC for contactor sizes E02(G)-E05(G)	\$14
F684	SZ-Z31	Fuji coil surge suppressor, varistor type, 24-48 VAC/DC for contactor sizes E1(G)-E4(G)	\$17
F685	SZ-Z32	Fuji coil surge suppressor, varistor type, 100-250 VAC/DC for contactor sizes E1(G)-E4(G)	\$17
F686	SZ-Z34	Fuji coil surge suppressor, RC type, 24-48 VAC/DC for contactor sizes E1-E4	\$17
F687	SZ-Z35	Fuji coil surge suppressor, RC type, 100-250 VAC/DC for contactor sizes E1-E4	\$17
F688	SZ-Z36	Fuji coil surge suppressor, RC type, 24-48 VAC/DC for contactor sizes E1G-E4G	\$17
F689	SZ-Z37	Fuji coil surge suppressor, RC type, 100-250 VAC/DC for contactor sizes E1G-E4G	\$17

Fuji Electric Mechanical Interlock and Reversing Kits			Aust\$
F725	SZ-RM	Fuji mechanical interlock unit for contactor sizes E02 to E4. Used when building a reversing starter, prevents both contactors from being pulled in at once.	\$16
F726	SZ-ERW1A	Fuji reversing connection kit for SC-E02 to SC-E05, for line side only. Choose the proper load side kit depending on application.	\$6
F727	SZ-ERW1B	Fuji load side reversing connection kit for SC-E02 to SC-E05. This kit is for wiring the load side when using contactors only or with a MMS device.	\$6
F728	SZ-ERW1D	Fuji load side reversing connection kit for SC-E02 to SC-E05, for wiring the load side when using two contactors with a thermal overload relay.	\$6
F729	SZ-ERW2A	Fuji reversing connection kit for SC-E1 to SC-E2S, for line side only. Choose the proper load side kit depending on application.	\$13
F730	SZ-ERW2B	Fuji load side reversing connection kit for SC-E1 to SC-E2S, for wiring the load side when using contactors only or with a MMS device.	\$13
F731	SZ-ERW2D	Fuji load side reversing connection kit for SC-E1 to SC-E2S, for wiring the load side when using two contactors with a thermal overload relay.	\$13
F732	SZ-ERW3A	Fuji reversing connection kit for SC-E3 to SC-E4, for line side only. Choose the proper load side kit depending on application.	\$23
F733	SZ-ERW3B	Fuji load side reversing connection kit for SC-E3 to SC-E4, for wiring the load side when using contactors only or with a MMS device.	\$23
F734	SZ-ERW3D	Fuji load side reversing connection kit for SC-E3 to SC-E4, for wiring the load side when using two contactors with a thermal overload relay.	\$23
Fuji Electric Terminal Covers			Aust\$
F736	SZ-N8T	Fuji terminal cover for contactor sizes 3NC4Q to 3NC4H, prevents contact with electrified terminals on contactor.	\$57
F737	SZ-N11T	Fuji terminal cover for contactor sizes 3NC5F to 3NC5H, prevents contact with electrified terminals on contactor.	\$70
F738	SZ-WN8T	Fuji thermal overload relay terminal cover for size 3NK4Q, prevents contact with electrified terminals on overload relay.	\$85
F739	SZ-WN10T	Fuji thermal overload relay terminal cover for size 3NK4H, prevents contact with electrified terminals on overload relay.	\$85
F740	SZ-WN11T	Fuji thermal overload relay terminal cover for size 3NK5H, prevents contact with electrified terminals on overload relay.	\$97
Fuji Electric Replacement Coils			Aust\$
F746	SZ-GSN5-100	Fuji replacement coil for contactor size SC-E5, 100-120 VAC/DC	\$153
F747	SZ-GSN6-100	Fuji replacement coil for contactor sizes SC-E6 and SC-E7, 100-120 VAC/DC	\$168
F748	SZ-GSN8-100	Fuji replacement coil for contactor sizes 3NC4Q0122 and 3NC4H0122, 100-120 VAC/DC	\$189
F749	SZ-GSN11-100	Fuji replacement coil for contactor sizes 3NC5F0122 and 3NC5H0122, 100-120 VAC/DC	\$208
F750	SZ-GSN5-200	Fuji replacement coil for contactor size SC-E5, 200-240 VAC/DC	\$153
F751	SZ-GSN6-200	Fuji replacement coil for contactor sizes SC-E6 and SC-E7, 200-240 VAC/DC	\$168
F754	SZ-GSN5-24	Fuji replacement coil for contactor size SC-E5, 24 VAC/DC	\$153
F755	SZ-GSN6-24	Fuji replacement coil for contactor sizes SC-E6 and SC-E7, 24 VAC/DC	\$88
F756	SZ-GSN8-24	Fuji replacement coil for contactor sizes 3NC4Q0E22 and 3NC4H0E22, 24 VAC/DC	\$189
F757	SZ-GSN11-24	Fuji replacement coil for contactor sizes 3NC5F0E22 and 3NC5H0E22, 24 VAC/DC	\$109

		Fuji Electric Manual Motor Starters	Aust\$
F700	BM3RHB-P16	Fuji manual motor starter, 45 mm frame width, rotary actuator, 0.1 to 0.16 FLA thermal overload trip rating, 2.1A instantaneous trip rating. For UL Type E listing, terminal cover BZ0TCRE and Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$63
F701	BM3RHB-P25	Fuji manual motor starter, 45 mm frame width, rotary actuator, 0.16 to 0.25 FLA thermal overload trip rating, 3.3A instantaneous trip rating. For UL Type E listing, terminal cover BZ0TCRE and Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$63
F702	BM3RHB-P40	Fuji manual motor starter, 45 mm frame width, rotary actuator, 0.25 to 0.40 FLA thermal overload trip rating, 5.2A instantaneous trip rating. For UL Type E listing, terminal cover BZ0TCRE and Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$63
F703	BM3RHB-P63	Fuji manual motor starter, 45 mm frame width, rotary actuator, 0.40 to 0.63 FLA thermal overload trip rating, 8.2A instantaneous trip rating. For UL Type E listing, terminal cover BZ0TCRE and Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$63
F704	BM3RHB-001	Fuji manual motor starter, 45 mm frame width, rotary actuator, 0.63 to 1.0 FLA thermal overload trip rating, 13A instantaneous trip rating. For UL Type E listing, terminal cover BZ0TCRE and Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$63
F705	BM3RHB-1P6	Fuji manual motor starter, 45 mm frame width, rotary actuator, 1 to 1.6 FLA thermal overload trip rating, 20.8A instantaneous trip rating. For UL Type E listing, terminal cover BZ0TCRE and Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$63
F706	BM3RHB-2P5	Fuji manual motor starter, 45 mm frame width, rotary actuator, 1.6 to 2.5 FLA thermal overload trip rating, 32.5A instantaneous trip rating. For UL Type E listing, terminal cover BZ0TCRE and Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$63
F707	BM3RHB-004	Fuji manual motor starter, 45 mm frame width, rotary actuator, 2.5 to 4 FLA thermal overload trip rating, 52A instantaneous trip rating. For UL Type E listing, terminal cover BZ0TCRE and Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$63
F708	BM3RHB-6P3	Fuji manual motor starter, 45 mm frame width, rotary actuator, 4 to 6.3 FLA thermal overload trip rating, 81.9A instantaneous trip rating. For UL Type E listing, terminal cover BZ0TCRE and Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$63
F709	BM3RHB-010	Fuji manual motor starter, 45 mm frame width, rotary actuator, 6.3 to 10 FLA thermal overload trip rating, 130A instantaneous trip rating. For UL Type E listing, terminal cover BZ0TCRE and Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$67
F710	BM3RHB-013	Fuji manual motor starter, 45 mm frame width, rotary actuator, 9 to 13 FLA thermal overload trip rating, 169A instantaneous trip rating. For UL Type E listing, terminal cover BZ0TCRE and Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$67
F711	BM3RHB-016	Fuji manual motor starter, 45 mm frame width, rotary actuator, 11 to 16 FLA thermal overload trip rating, 208A instantaneous trip rating. For UL Type E listing, terminal cover BZ0TCRE and Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$67
F712	BM3RHB-020	Fuji manual motor starter, 45 mm frame width, rotary actuator, 14 to 20 FLA thermal overload trip rating, 260A instantaneous trip rating. For UL Type E listing, terminal cover BZ0TCRE and Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$67
F713	BM3RHB-025	Fuji manual motor starter, 45 mm frame width, rotary actuator, 19 to 25 FLA thermal overload trip rating, 325A instantaneous trip rating. For UL Type E listing, terminal cover BZ0TCRE and Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$79
F714	BM3RHB-032	Fuji manual motor starter, 45 mm frame width, rotary actuator, 24 to 32 FLA thermal overload trip rating, 416A instantaneous trip rating. For UL Type E listing, terminal cover BZ0TCRE and Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$101
F715	BM3VHB-010	Fuji manual motor starter, 55 mm frame width, rotary actuator, 6.3 to 10 FLA thermal overload trip rating, 130A instantaneous trip rating. For UL Type E listing, Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$156
F716	BM3VHB-013	Fuji manual motor starter, 55 mm frame width, rotary actuator, 9 to 13 FLA thermal overload trip rating, 169A instantaneous trip rating. For UL Type E listing, Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$156
F717	BM3VHB-016	Fuji manual motor starter, 55 mm frame width, rotary actuator, 11 to 16 FLA thermal overload trip rating, 208A instantaneous trip rating. For UL Type E listing, Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$156
F718	BM3VHB-020	Fuji manual motor starter, 55 mm frame width, rotary actuator, 14 to 20 FLA thermal overload trip rating, 260A instantaneous trip rating. For UL Type E listing, Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$156
F719	BM3VHB-025	Fuji manual motor starter, 55 mm frame width, rotary actuator, 19 to 25 FLA thermal overload trip rating, 325A instantaneous trip rating. For UL Type E listing, Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$181
F720	BM3VHB-032	Fuji manual motor starter, 55 mm frame width, rotary actuator, 24 to 32 FLA thermal overload trip rating, 416A instantaneous trip rating. For UL Type E listing, Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$192
F721	BM3VHB-040	Fuji manual motor starter, 55 mm frame width, rotary actuator, 28 to 40 FLA thermal overload trip rating, 520A instantaneous trip rating. For UL Type E listing, Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$192
F722	BM3VHB-050	Fuji manual motor starter, 55 mm frame width, rotary actuator, 35 to 50 FLA thermal overload trip rating, 650A instantaneous trip rating. For UL Type E listing, Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$200
F723	BM3VHB-063	Fuji manual motor starter, 55 mm frame width, rotary actuator, 45 to 63 FLA thermal overload trip rating, 819A instantaneous trip rating. For UL Type E listing, Short Circuit Alarm contact block BZ0TKUAB must be added to the MMS.	\$200

Fuji Electric Auxiliary Contacts for Manual Motor Starters			Aust\$
F760	BZ0WIA	Fuji auxiliary contact block for MMS, 1 N.O. contact mounts into the front of the MMS	\$7
F761	BZ0WIB	Fuji auxiliary contact block for MMS, 1 N.C. contact mounts into the front of the MMS	\$7
F762	BZ0WUAAAL	Fuji auxiliary contact block for MMS, 2 N.O. contacts mount onto the left side of the MMS	\$10
F763	BZ0WUABL	Fuji auxiliary contact block for MMS, 1 N.O. and 1 N.C. contacts mount onto the left side of the MMS	\$10
F764	BZ0WUBBL	Fuji auxiliary contact block for MMS, 2 N.C. contacts mount onto the left side of the MMS	\$10
F765	BZ0KIA	Fuji alarm contact block for MMS, N.O. contact operates when the MMS trips due to overload, phase loss, or short circuit. It is not linked to the ON/OFF operation. Mounts into the front of the MMS. Note: Can be checked with the test trip function.	\$7
F766	BZ0KIB	Fuji alarm contact block for MMS, N.C. contact operates when the MMS trips due to overload, phase loss, or short circuit. It is not linked to the ON/OFF operation. Mounts into the front of the MMS. Note: Can be checked with the test trip function.	\$7
F767	BZ0WKUAA	Fuji auxiliary/alarm contact block. Alarm and auxiliary contacts operate when the MMS trips due to overload, phase loss, or short circuit. The alarm contact is not linked to the ON/OFF operation. Block contains 1 N.O. auxiliary contact and 1 N.O. alarm contact.	\$13
F768	BZ0TKUAB	Fuji short circuit alarm contact block. Both contacts operate ONLY when the MMS trips due to a short circuit. The alarm contact is not linked to the ON/OFF operation. Block contains 1 N.O. and 1 N.C. contact. The power to the MMS can be turned ON after pressing the blue reset button on the alarm contact. Required when using the MMS in a UL Type E application.	\$16
Fuji Electric Shunt and Undervoltage Trip Devices for Manual Motor Starters			Aust\$
F769	BZ0FAZU	Fuji shunt trip device used to remotely trip the MMS, 24 VAC 50/60 Hz. This device mounts to the right side of the MMS, may not be used together with an undervoltage trip device.	\$22
F770	BZ0FDZU	Fuji shunt trip device used to remotely trip the MMS, 120 VAC 60 Hz. This device mounts to the right side of the MMS, may not be used together with an undervoltage trip device.	\$22
F771	BZ0FKZUD	Fuji shunt trip device used to remotely trip the MMS, 24 VDC. This device mounts to the right side of the MMS, may not be used together with an undervoltage trip device.	\$22
F772	BZ0RAZ2U	Fuji undervoltage trip device used to trip the MMS when the control circuit voltage drops below the specified level, 24 VAC 60Hz. This device mounts to the right side of the MMS, may not be used together with a shunt trip device.	\$22
F773	BZ0RDZU	Fuji undervoltage trip device used to trip the MMS when the control circuit voltage drops below the specified level, 120 VAC 60Hz. This device mounts to the right side of the MMS, may not be used together with a shunt trip device.	\$22
F774	BZ0R4ZU	Fuji undervoltage trip device used to trip the MMS when the control circuit voltage drops below the specified level, 460-480 VAC 60Hz. This device mounts to the right side of the MMS, may not be used together with a shunt trip device.	\$22
Fuji Electric Operating Handles for Manual Motor Starters			Aust\$
F775	BZ0VBBL	External operating handle for MMS, black, used to operate the MMS mounted in the enclosure from the outside of the panel. Includes interlocking capability with a screw release and Off lock function. For BM3RH	\$32
F776	BZ0VYRL	External operating handle for MMS, red/yellow, used to operate the MMS mounted in the enclosure from the outside of the panel. Includes interlocking capability with a screw release and Off lock function. For BM3RH series MMS, IP54 rated.	\$34
F777	BZ0VBBM	External operating handle for MMS, black, used to operate the MMS mounted in the enclosure from the outside of the panel. Includes interlocking capability with a screw release and Off lock function. For BM3V series MMS, IP54 rated.	\$32
F778	BZ0VYRM	External operating handle for MMS, red/yellow, used to operate the MMS mounted in the enclosure from the outside of the panel. Includes interlocking capability with a screw release and Off lock function. For BM3V series MMS, IP54 rated.	\$34

Fuji Electric Mounting and Busbar Kits for Manual Motor Starters			Aust\$
F779	BZ0SET	Screw mount kit for MMS, used only when DIN rail mounting is not used. Lugs push into the back of the MMS and provide a sturdy lug for direct panel mounting. 10 pieces per package.	\$7
F780	BZ0BR02A	Busbar for connecting 2 BM3RH MMS units without accessories. Requires 1 BZ0BFRA feed-in terminal for connecting line power to bus.	\$19
F781	BZ0BR03A	Busbar for connecting 3 BM3RH MMS units without accessories. Requires 1 BZ0BFRA feed-in terminal for connecting line power to bus.	\$17
F782	BZ0BR04A	Busbar for connecting 4 BM3RH MMS units without accessories. Requires 1 BZ0BFRA feed-in terminal for connecting line power to bus.	\$20
F783	BZ0BR05A	Busbar for connecting 5 BM3RH MMS units without accessories. Requires 1 BZ0BFRA feed-in terminal for connecting line power to bus.	\$22
F784	BZ0BR12A	Busbar for connecting 2 BM3RH MMS units with 1 (9 mm wide) accessory. Requires 1 BZ0BFRA feed-in terminal for connecting line power to the bus.	\$16
F785	BZ0BR13A	Busbar for connecting 3 BM3RH MMS units with 1 (9 mm wide) accessory. Requires 1 BZ0BFRA feed-in terminal for connecting line power to the bus.	\$19
F786	BZ0BR14A	Busbar for connecting 4 BM3RH MMS units with 1 (9 mm wide) accessory. Requires 1 BZ0BFRA feed-in terminal for connecting line power to the bus.	\$22
F787	BZ0BR15A	Busbar for connecting 5 BM3RH MMS units with 1 (9 mm wide) accessory. Requires 1 BZ0BFRA feed-in terminal for connecting line power to the bus.	\$23
F788	BZ0BV02A	Busbar for connecting 2 BM3V MMS units without accessories. Requires 1 BZ0BFVA feed-in terminal for connecting line power to the bus.	\$30
F789	BZ0BV03A	Busbar for connecting 3 BM3V MMS units without accessories. Requires 1 BZ0BFVA feed-in terminal for connecting line power to the bus.	\$39
F790	BZ0BV04A	Busbar for connecting 4 BM3V MMS units without accessories. Requires 1 BZ0BFVA feed-in terminal for connecting line power to the bus.	\$47
F791	BZ0BV12A	Busbar for connecting 2 BM3V MMS units with 1 (9 mm wide) accessory. Requires 1 BZ0BFVA feed-in terminal for connecting line power to the bus.	\$34
F792	BZ0BV13A	Busbar for connecting 3 BM3V MMS units with 1 (9 mm wide) accessory. Requires 1 BZ0BFVA feed-in terminal for connecting line power to the bus.	\$42
F793	BZ0BV14A	Busbar for connecting 4 BM3V MMS units with 1 (9 mm wide) accessory. Requires 1 BZ0BFVA feed-in terminal for connecting line power to the bus.	\$49
F794	BZ0BFRA	Fuji terminal block for incoming power to busbar system, used with BM3RH busbars. Maximum current 64A, maximum wire size 8 AWG	\$17
F795	BZ0BFVA	Fuji terminal block for incoming power to busbar system, used with BM3V busbars. Maximum current 126A, maximum wire size 4 AWG	\$35
F796	BZ0BCRA	Fuji MMS busbar cover, for unused exposed busbar pins on the BM3RH busbar system	\$4
F797	BZ0BCVA	Fuji MMS busbar cover, for unused exposed busbar pins on the BM3V busbar system	\$6
F798	BZ0TCRE	Line side terminal cover for Fuji BM3RHB MMS devices. This cover is required only if the MMS is to be used in a UL Type E application.	\$10
Fuji Electric Link Modules for Manual Motor Starters			Aust\$
F799	BZ0LRE22AA	Fuji link module for electrically connecting BM3RH MMS to SC-E02, E03, E04 or E05 contactors (with AC coils)	\$12
F800	BZ0LRE22GA	Fuji link module for electrically connecting BM3RH MMS to SC-E02, E03, E04 or E05 contactors (with DC coils)	\$14
F801	BZ0LRE32AA	Fuji link module for electrically connecting BM3RH MMS to SC-E1 contactors (with AC coils)	\$13
F802	BZ0LRE32GA	Fuji link module for electrically connecting BM3RH MMS to SC-E1 contactors (with DC coils)	\$16
F803	BZ0LVE51AA	Fuji link module for electrically connecting BM3V MMS to SC-E1, E2 or E2S contactors (with AC coils)	\$14
F804	BZ0LVE51GA	Fuji link module for electrically connecting BM3V MMS to SC-E1, E2 or E2S contactors (with DC coils)	\$17
F805	BZ0LVE65AA	Fuji link module for electrically connecting BM3V MMS to SC-E3 contactors (with AC coils)	\$17
F806	BZ0LVE65GA	Fuji link module for electrically connecting BM3V MMS to SC-E3 contactors (with DC coils)	\$20
Fuji Electric Baseplates for Manual Motor Starters			Aust\$
F808	BZ0BPVE22A	Fuji baseplate for mounting MMS and contactor for a combination starter. Couples MMS BM3RH series to SC-E02, E03, E04 or E05 contactors with AC or DC coils. Use with BZ0LRE22AA link module for AC Coils or BZ0LRE22GA link module for DC coils.	\$16
F809	BZ0BPVE32A	Fuji baseplate for mounting MMS and contactor for a combination starter. Couples MMS BM3RH series to SC-E1 contactors with AC or DC coils. Use with BZ0LRE32AA link module for AC coils or BZ0LRE32GA link module for DC coils.	\$17
F810	BZ0BPVE51A	Fuji baseplate for mounting MMS and contactor for a combination starter. Couples MMS BM3V series to SC-E1, E2 or E2S contactors with AC or DC coils. Use with BZ0LVE51AA link module for AC coils or BZ0LVE51GA link module for DC coils.	\$19
F811	BZ0BPVE65A	Fuji baseplate for mounting MMS and contactor for a combination starter. Couples MMS BM3V series to SC-E3 contactors with AC or DC coils. Use with BZ0LVE65AA link module for AC coils or BZ0LVE65GA link module for DC coils.	\$22

		Manual Starter/Protectors and Accessories	Aust\$
	MS25-16	Manual starter protector with thermal overload release, setting range from 0.1 to 0.16 amps	\$59
	MS25-25	Manual starter protector with thermal overload release, setting range from 0.16 to 0.25 amps	\$59
	MS25-40	Manual starter protector with thermal overload release, setting range from 0.25 to 0.4 amps	\$59
	MS25-63	Manual starter protector with thermal overload release, setting range from 0.4 to 0.63 amps	\$59
	MS25-100	Manual starter protector with thermal overload release, setting range from 0.63 to 1 amp	\$59
	MS25-160	Manual starter protector with thermal overload release, setting range from 1 to 1.6 amps	\$59
	MS25-250	Manual starter protector with thermal overload release, setting range from 1.6 to 2.5 amps	\$59
	MS25-400	Manual starter protector with thermal overload release, setting range from 2.5 to 4 amps	\$59
	MS25-630	Manual starter protector with thermal overload release, setting range from 4 to 6.3 amps	\$59
	MS25-1000	Manual starter protector with thermal overload release, setting range from 6.3 to 10 amps	\$70
	MS25-1600	Manual starter protector with thermal overload release, setting range from 10 to 16 amps	\$70
	MS25-2000	Manual starter protector with thermal overload release, setting range from 16 to 20 amps	\$75
	MS25-2500	Manual starter protector with thermal overload release, setting range from 20 to 25 amps	\$85
	MS25-PS11	PS11 auxiliary switch for manual starter protectors, 1 N.O., 1 N.C. contact	\$14
	UMP45	Mounting plate adapter, for mounting two DIN rail devices on one DIN rail. Use with contactor and MSP to create a complete motor starter/protection device.	\$15
	MS25-A120	Shunt release for MSPs, 120V/60Hz	\$30
	MS25-U220	Undervoltage release for MSPs, 220V/60Hz	\$30
	MS25-U440	Undervoltage release for MSPs, 440V/60Hz	\$30
		Motor Monitoring Relays	Aust\$
	PMRU-1C-480A	Phase monitor relay, provides protection against phase reversal, phase loss, phase unbalance, undervoltage, and overvoltage; 10A SPDT output contacts, 8-pin octal base. Works with 3-phase systems from 208V to 480V; compatible with most Delta or Wye configurations. Relay becomes UL listed when used with relay socket 70169-D.	\$99
	SM1001	Speed Monitor, 1-6000 RPM, 0.1-1000Hz 230VAC/24VDC, PNP/NPN output	\$275
		Fuji Electric MCCBs	Aust\$
F201	BW125JAGU-3P015SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW125 series, 125 Amp frame, UL489 rated for 15A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$227
F202	BW125JAGU-3P020SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW125 series, 125 Amp frame, UL489 rated for 20A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$227
F203	BW125JAGU-3P030SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW125 series, 125 Amp frame, UL489 rated for 30A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$227
F204	BW125JAGU-3P040SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW125 series, 125 Amp frame, UL489 rated for 40A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$227
F205	BW125JAGU-3P050SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW125 series, 125 Amp frame, UL489 rated for 50A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$227
F206	BW125JAGU-3P060SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW125 series, 125 Amp frame, UL489 rated for 60A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$227
F207	BW125JAGU-3P070SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW125 series, 125 Amp frame, UL489 rated for 70A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$227
F208	BW125JAGU-3P075SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW125 series, 125 Amp frame, UL489 rated for 75A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$227
F209	BW125JAGU-3P080SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW125 series, 125 Amp frame, UL489 rated for 80A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$227
F210	BW125JAGU-3P090SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW125 series, 125 Amp frame, UL489 rated for 90A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$227
F211	BW125JAGU-3P100SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW125 series, 125 Amp frame, UL489 rated for 100A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$227
F212	BW125JAGU-3P125SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW125 series, 125 Amp frame, UL489 rated for 125A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$227
F213	BW250JAGU-3P125SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW250 series, 250 Amp frame, UL489 rated for 125A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$520
F214	BW250JAGU-3P150SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW250 series, 250 Amp frame, UL489 rated for 150A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$520
F215	BW250JAGU-3P160SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW250 series, 250 Amp frame, UL489 rated for 160A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$520

F216	BW250JAGU-3P175SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW250 series, 250 Amp frame, UL489 rated for 175A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$520
F217	BW250JAGU-3P200SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW250 series, 250 Amp frame, UL489 rated for 200A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$520
F218	BW250JAGU-3P225SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW250 series, 250 Amp frame, UL489 rated for 225A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$520
F219	BW250JAGU-3P250SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW250 series, 250 Amp frame, UL489 rated for 250A, 600 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals and terminal covers included	\$520
F220	BW400SAGU-3P250SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW400 series, 400 Amp frame, UL489 rated for 250A, 480 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals included	\$924
F221	BW400SAGU-3P300SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW400 series, 400 Amp frame, UL489 rated for 300A, 480 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals included	\$924
F222	BW400SAGU-3P350SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW400 series, 400 Amp frame, UL489 rated for 350A, 480 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals included	\$924
F223	BW400SAGU-3P400SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW400 series, 400 Amp frame, UL489 rated for 400A, 480 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals included	\$924
F224	BW630RAGU-3P500SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW630 series, 630 Amp frame, UL489 rated for 500A, 480 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals included	\$1,357
F225	BW630RAGU-3P600SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW630 series, 630 Amp frame, UL489 rated for 600A, 480 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals included	\$1,357
F226	BW800RAGU-3P700SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW800 series, 800 Amp frame, UL489 rated for 700A, 480 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals included	\$1,819
F227	BW800RAGU-3P800SB	Molded Case Circuit Breaker (MCCB), Fuji Electric BW800 series, 800 Amp frame, UL489 rated for 800A, 480 VAC, 3-pole unit with thermal magnetic trip, panel mountable, line and load lug terminals included	\$1,819
F301	BW9W1SG0	Auxiliary contact switch, field installable, use with Fuji Electric BW125 and BW250 series MCCBs; SPDT, 20 AWG lead wires 19.69 inches in length, left side mounting only	\$29
F302	BW9W1SHA	Auxiliary contact switch, field installable, use with Fuji Electric BW400, BW630 and BW800 series MCCBs; SPDT, 20 AWG lead wires 19.69 inches in length, left side mounting only	\$29
F303	BW9FRG0	DC shunt trip, field installable, use with Fuji Electric BW125 and BW250 series MCCBs; 24 VDC/AC, 20 AWG lead wires 19.69 inches in length, left and right side mounting	\$60
F304	BW9FHA-R	DC shunt trip, field installable, use with Fuji Electric BW400, BW630 and BW800 series MCCBs; 24-48 VDC/AC, 20 AWG lead wires 19.69 inches in length, left side mounting only	\$60
F305	BW9FAG0	AC shunt trip, field installable, use with Fuji Electric BW125 and BW250 series MCCBs; 100-120 VAC, 20 AWG lead wires 19.69 inches in length, left and right side mounting	\$60
F306	BW9FHA-A	AC shunt trip, field installable, use with Fuji Electric BW400, BW630 and BW800 series MCCBs; 100-240 VAC, 20 AWG lead wires 19.69 inches in length, left side mounting only	\$60
F307	BW9RGAR	DC undervoltage release, field installable, use with Fuji Electric BW125 and BW250 series MCCBs; 24 VDC, 20 AWG lead wires 19.69 inches in length, left side mounting only	\$60
F308	BW9RHA-R	DC undervoltage release, field installable, use with Fuji Electric BW400, BW630 and BW800 series MCCBs; 24-48 VDC/AC, 20 AWG lead wires 19.69 inches in length, left side mounting only	\$60
F309	BW9RGAT	AC undervoltage release, field installable, use with Fuji Electric BW125 and BW250 series MCCBs; 110-130 VAC, 20 AWG lead wires 19.69 inches in length, left side mounting only	\$60
F310	BW9RHA-1	AC undervoltage release, field installable, use with Fuji Electric BW400, BW630 and BW800 series MCCBs; 120-130 VAC, 20 AWG lead wires 19.69 inches in length, left side mounting only	\$60
F311	BW9SL0CA-3	Replacement lugs, use with Fuji Electric BW125 series MCCBs, up to 125 Amps, 3 pieces per pack	\$64
F312	BW9SL0GA-3	Replacement lugs, use with Fuji Electric BW250 series 125A, 150A, 160A and 175A MCCBs, 3 pieces per pack	\$73
F313	BW9SL1GA-3	Replacement lugs, use with Fuji Electric BW250 series 200A, 225A and 250A MCCBs, 3 pieces per pack	\$79
F314	BW9V0CA	Rotary handle, NEMA 12, use with Fuji Electric BW125 series MCCBs; Shaft length 0.39 inches, 4.134 inches maximum mounting depth. Use optional shaft BW9VSG0 for 9.843 inches maximum mounting depth.	\$57
F315	BW9V0GA	Rotary handle, NEMA 12, use with Fuji Electric BW250 series MCCBs; Shaft length 0.39 inches, 4.134 inches maximum mounting depth. Use optional shaft BW9VSG0 for 9.843 inches maximum mounting depth.	\$57
F316	BW9V0HA	Rotary handle, NEMA 12, use with Fuji Electric BW400 series MCCBs; Shaft length 0.39 inches, 7.48 inches maximum mounting depth. Use optional shaft BZ-VS2 for 9.843 inches maximum mounting depth.	\$86
F317	BW9V0JA	Rotary handle, NEMA 12, use with Fuji Electric BW630 and BW800 series MCCBs; Shaft length 0.39 inches, 7.48 inches maximum mounting depth. Use optional shaft BZ-VS2 for 9.843 inches maximum mounting depth.	\$101
F318	BW9VSG0	Rotary handle shaft, optional, use with Fuji Electric BW9V0CA and BW9V0GA rotary handles, 9.843 inches maximum mounting depth	\$12
F319	BZ-VS2	Rotary handle shaft, optional, use with Fuji Electric BW9V0HA and BW9V0JA rotary handles, 9.843 inches maximum mounting depth	\$12
F320	BW9F0CA-15	Flange disconnect handle, NEMA 12, use with Fuji Electric BW125 series MCCBs, 1.5m (4.92 ft.) flex cable length, flange mounting, lockable	\$289

F321	BW9F0CA-20	Flange disconnect handle, NEMA 12, use with Fuji Electric BW125 series MCCBs, 2m (6.56 ft.) flex cable length, flange mounting, lockable	\$289
F322	BW9F0GA-15	Flange disconnect handle, NEMA 12, use with Fuji Electric BW250 series MCCBs, 1.5m (4.92 ft.) flex cable length, flange mounting, lockable	\$312
F323	BW9F0GA-20	Flange disconnect handle, NEMA 12, use with Fuji Electric BW250 series MCCBs, 2m (6.56 ft.) flex cable length, flange mounting, lockable	\$312
F324	BW9F0HA-15	Flange disconnect handle, NEMA 12, use with Fuji Electric BW400 series MCCBs, 1.5m (4.92 ft.) flex cable length, flange mounting, lockable	\$337
F325	BW9F0HA-20	Flange disconnect handle, NEMA 12, use with Fuji Electric BW400 series MCCBs, 2m (6.56 ft.) flex cable length, flange mounting, lockable	\$385
F351	BW9BTHA-L3W	Terminal cover, use with Fuji Electric BW400 series MCCBs, for line side and load side terminals, 2 pieces per pack	\$57
F352	BW9BTJA-L3W	Terminal cover, use with Fuji Electric BW630 and BW800 series MCCBs, for line side and load side terminals, 2 pieces per pack	\$62
F353	BW9Q1CA	Lockout attachment, use to lock out BW125 and BW250 series MCCBs, lock not included	\$11
F354	BW9QNHA	Lockout attachment, use to lock out BW400, BW630, and BW800 series MCCBs, lock not included	\$26
F355	WA21FUFA	Operator adapter plate for use with Fuji Electric series BW9F series flex handle mechanisms	\$160
	Type	Non-Fused Panel Disconnects Switches	Aust\$
	SD1-016-BR	Load switch, non-fused, 16A rating, with rotary black handle, UL508 rated, DIN rail or panel mountable	\$39
	SD1-025-BR	Load switch, non-fused, 25A rating, with rotary black handle, UL508 rated, DIN rail or panel mountable	\$39
	SD1-032-BR	Load switch, non-fused, 32A rating, with rotary black handle, UL508 rated, DIN rail or panel mountable	\$39
	SD1-040-BR	Load switch, non-fused, 40A rating, with rotary black handle, UL508 rated, DIN rail or panel mountable	\$45
	SD2-063-BR	Load switch, non-fused, 63A rating, with rotary black handle, UL508 rated, DIN rail or panel mountable	\$59
	SD2-080-BR	Load switch, non-fused, 80A rating, with rotary black handle, UL508 rated, DIN rail or panel mountable	\$65
	SD2-100-BR	Load switch, non-fused, 100A rating, with rotary black handle, UL508 rated, DIN rail or panel mountable	\$69
	SD2-125-BR	Load switch, non-fused, 125A rating, with rotary black handle, UL508 rated, DIN rail or panel mountable	\$79
	SD1-016-RR	Load switch, non-fused, 16A rating, with rotary red handle, UL508 rated, DIN rail or panel mountable	\$39
	SD1-025-RR	Load switch, non-fused, 25A rating, with rotary red handle, UL508 rated, DIN rail or panel mountable	\$39
	SD1-032-RR	Load switch, non-fused, 32A rating, with rotary red handle, UL508 rated, DIN rail or panel mountable	\$39
	SD1-040-RR	Load switch, non-fused, 40A rating, with rotary red handle, UL508 rated, DIN rail or panel mountable	\$45
	SD2-063-RR	Load switch, non-fused, 63A rating, with rotary red handle, UL508 rated, DIN rail or panel mountable	\$59
	SD2-080-RR	Load switch, non-fused, 80A rating, with rotary red handle, UL508 rated, DIN rail or panel mountable	\$65
	SD2-100-RR	Load switch, non-fused, 100A rating, with rotary red handle, UL508 rated, DIN rail or panel mountable	\$69
	SD2-125-RR	Load switch, non-fused, 125A rating, with rotary red handle, UL508 rated, DIN rail or panel mountable	\$79
		Remote Handles & Accessories	Aust\$
	SD1-4P	Additional 4th pole for SD1 non-fused load switches, 40A rating	\$25
	SD2-4P	Additional 4th pole for SD2 non-fused load switches, 125A rating	\$25
	SD1-GP	Ground pole for SD1 non-fused load switches	\$25
	SD2-GP	Ground pole for SD2 non-fused load switches	\$25
	SD1-NP	Neutral pole for SD1 non-fused load switches	\$25
	SD2-NP	Neutral pole for SD2 non-fused load switches	\$25
	SD1-AUX	Auxiliary contact for SD1 non-fused load switches, contains one N.O. and one N.C. contact	\$25
	SD2-AUX	Auxiliary contact for SD2 non-fused load switches, contains one N.O. and one N.C. contact	\$25
	SD-CON	Connector, 6-8 poles, to connect two SD series non-fused load switches to one remote operator. Use with 200 mm max. shaft length.	\$30
	SD-S100	Remote operator shaft, for SD series switches, accomodates up to 100mm distance to switch. Purchase handle separately.	\$10
	SD-S200	Remote operator shaft, for SD series switches, accomodates up to 200mm distance to switch. Purchase handle separately.	\$10
	SD-S300	Remote operator shaft, for SD series switches, accomodates up to 300mm distance to switch. Purchase handle separately.	\$10
	SD-HB	Remote black handle for SD series non-fused load switches, non-defeatable	\$12
	SD-HRY	Remote red-yellow handle for SD series non-fused load switches, non-defeatable	\$12